




Measurement instruction for roof windows pleated blind.




Select the window



Measure





Mount the blind



Dimensions are provided in millimeters (mm).

Pic. 1.



By measuring the width and height, check the dimensions inside the skylight recess, right next to the glass.
(Pic.1)

When entering the desired dimensions, enter the values of your measurements in the configurator:

Width = A

Height = B